ASSEMBLY MANUAL

AKILA CHASSIS SYSTEM

AKILA d.o.o

2023



N	Name
1	Center part
2	Foreend Lite
3	ARCA Foreend
4	Screw M6x10 (Hex5)
5	Foreend grip
6	Screw M6x20 (Hex4)
7	Screw cap
8	Grip
9	Screw M6x45 (Hex 5)
10	Spring Washer 6
11	Washer 6 (for plastic set 2psc. washer)
12	Thread bushing
13	Ring
14.1-14.2	Right or Left foldingstock position
15	Spacer
16	Screw M5x16 (Hex 4)
17	Screw M5x16 (Torx 25)
18	Buttstock M
19	Buttstock lite
20	Cheekpiece
21	Screw M5x10 (Hex 3)
22	Small screw cap
23	Cover
24	Screw M4x10 (Torx 20)


M6X45
M6X10
M5X16
M6X20
M5X10
M5X16
M4X10
5
5
4
4
3
T25
T20

T27 T25 T20 6 5 4 3 2 1.5
TORX
MM